

RP76

User Manual

Table of Contents

1、 INSTRUCTION.....	3
2、 SUMMARISATION	4
2.1、 MAIN FEATURES.....	4
3、 TECHNICAL SPECIFICATIONS.....	4
4、 PRINTER INSTALLATION AND OPERATION.....	6
4.1、 PRINTER DISASSEMBLING AND ASSEMBLY.....	6
4.2、 PRINTER CONNECTION METHOD	7
4.3、 PAPER ROLL INSTALLATION.....	8
4.4、 RIBBON INSTALLATION.....	9
5、 PRINTER SWITCHES, BUTTONS AND INDICATOR LIGHT.....	10
5.1 POWER SWITCH.....	10
5.2 BUTTONS AND INDICATOR.....	10
5.3 DIP SWITCH SETTINGS.....	11
6、 PRINTER SELF-TEST PRINTING	12
7、 PRINTER SERIAL PORT	12
8、 PRINTER PARALLEL PORT	13
9、 PRINTER CASH DRAWER PORT.....	134
10、 BLACK MARK POSITION CONTROL INSTRUCTIONS.....	15
10.1 PRINTING MECHANISM AND PRINTING CONTROL RELEVANT PARAMETERS	155
10.2 BLACK MARK PRINTING NOTE.....	155
10.3 BLACK MARK POSITIONING	155
11、 PRINTER CLEANING.....	166
12、 TROUBLESHOOTING	166
12.1 INDICATOR LIGHT ON THE CONTROL BOARD DOES NOT LIGHT	166
12.2 INDICATOR LIGHT NORMAL , BUT PRINTER NOT PRINT.....	167
12.3 PRINTER HAS SOUND , BUT DID NOT PRINT	17
12.4 PRINTING VAGUELY	177
12.5 PRINTING LACK OF A LINE	177

1、 INSTRUCTION

RP76 printer is POS impact dot matrix receipt printer with stable performance , high reliability and simple operation. It is widely used in supermarkets, shopping malls , hospitals , restaurants , banks , gas stations , toll collection and other places for its high cost effective .

Safety Instruction

Please read the content of the following carefully before using the printer , and strictly followed it.

1.Warnings:

Warning: Do not touch the printer cutter or paper tearing cutter.

Warning: The print head is the heat components. Do not touch the print head and the peripheral components during the printing process or just finishing the printing.

2. Precautions

- (1) The printer should be put on solid place. Don't put printer on vibration and shocking place .
- (2) Don't print or save printer in high-temperature, high-humidity and heavily polluted place.
- (3) Printer adapter should be connected to a properly grounded socket. Don't use the same socket together with large motors or other equipment that may cause voltage fluctuations.
- (4) Avoid water or conductive material (such metal) going into the inside of the printer, once happen, should turn off the power immediately.
- (5) If long time not use printers, should disconnect the adapter power.
- (6) Don't disassemble the printer for overhaul or transformation.
- (7) Please only use the adapter, which is together with printer
- (8) To ensure the quality and lifetime of printer , we recommend to use high-quality thermal paper and ribbon .
- (9) Make sure the printer power is turned off when Pull or plug connection lines.
- (10) When Pull or plug power cord, please hold at the cord end, which is marked with arrow(do not pull the soft part of the cord) .
- (11) Please keep this manual for reference.

2、SUMMARISATION

2.1、Main Features


- High quality printing
- Low noise and high speed.
- Support cash drawer driver
- Compact and attractive appearance
- Reasonable structure , easy operation and maintenance
- Interface optional : USB, parallel, serial
- Paper source sensor , automatic paper loading , and automatic detection of paper loading
- Character can be enlarged , bold , underlined print; character line spacing and left &right print spacing could be adjusted.
- Support different densities bitmap and download graphics print
- Support black mark detection position printing.
- Less power consumption and low running costs
- Compatilbe with ESC / POS

2、 TECHNICAL SPECIFICATIONS

- Print Method: 9-pin Impact Dot Matrix
- Print head performance:
Print head pins : 9-pin impact Diameter : 0.305 mm
Print density : 385 dots / line (half dot) , 400 dots / line (half dot)
Print head life: 300 X 106 impacts per needle
- Effective print width : 42CPL (7X9) / 35CPL (9X9)
40CPL(7X9)/33CPL(9X9)
- Print speed : 4.5lines / sec
- Feed speed : 120 mm / sec
- Printer interface:

USB interface: Universal USB interface (B standard).


Serial Interface: DB9 female interface , baud rate can be 4800bps, 9600bps, 19200bps or 38400bps.optional(can be adjusted via DIP switches) . No parity data structure, 8 data bits , 1 stop bit , supports RTS / CTS and XON / XOFF handshake protocol.



Serial Port

USB Cash Drawer Power

Parallel interface: 25PIN Parallel(male) bi-directional parallel interface, 8-bit parallel interface, support the BUSY/nAck handshake protocol.



Parallel Interface

USB Cash Drawer Power

Cash Drawer control : 6-wire RJ-11 socket, drive the cash drawer action via output DC 24V/1A signals

- **Printer Character**

ASCII Character set:

Font A, 9X9 dots , 1.6 (W) X3.1 (H) mm

Font B, 7X9 dots , 1.2 (W) X3.1 (H) mm

GB2312: 16X16 dots , 2.7 (W) X2.7 (H) mm

Code Page: PC437、Katakana、PC850、PC860、PC863、PC865、WPC1252、PC866、PC852 and PC858. Support up to 10 International Language.

- **Paper Specification**

Paper types: high-quality 1 linked ordinary continuous paper or 2-3 self - copy paper.

Paper width : 76.0 ± 0.5 mm

Paper roll outer diameter (Max.) : Φ75 mm

Paper roll diameter (Min.) : Φ12 mm

Single-layer paper thickness : 0.06 to 0.085 mm

Multi layer paper thickness: 0.05 to 0.08 mm, total thickness<0.20 mm

- **Ribbon Model: Cassette Ribbon ERC-39(purple or black)**

- **Printer Reliability : 10 million lines (MCBF)**

- **Black mark Detection:** black mark printed on front right side, the black mark length (along feed paper direction) 5 mm, minimum Width 8 mm.

Black mark reflectivity < 10% , the other part of the page with black mark reflectivity > 75%

- Command type: compatible with ESC/POS

Character printing: support ANK character , self- defined characters and chinese characters double width , double height printing and character space is adjustable.

Dot printing : support different density dot and download graphics printing

- Printer adaptor:

Adaptor input voltage: AC 110V/220V, 50~60Hz

Adapter Output Voltage: DC 24V/2.5A

Printer input voltage: DC 24V/2.5A

- Printer weight : about 1.6 kg (excluding paper roll)

- Size: 260 (L) x 160 (W) x 130 (H) mm

- Environment :

Operating temperature : 0 ~ 50 ° C Operating Humidity : 10 to 80%

Storage Temperature : -10 ~ 60 ° C Storage Humidity : 10 to 90%

- Model::

RP76US USB + SERIAL


RP76UP USB + PARALLEL


4、 RINTER INSTALLATION AND OPERATION

4.1、 Printer Disassembling And Installation

Checking spare parts:

After opening the box, please check the Matching parts , if something is missing please contact the supplier or manufacturer .






4.2、PRINTER CONNECTION METHOD

(1) The printer and the PC should be closed and communication cable is inserted in the printer connection port. The other side of communication cable (serial cable is 9-pin connector and parallel cable is 25 -pin connector) is inserted in the host PC 's serial / parallel / USB

(2) If cash drawer can be open electrically , put the RJ-11 connector in the printer 's cash drawer interface (cash drawer specification must comply with the printer cash drawer driver specification)



Note:

(1) First, plugged printer's power plug DC24V, and then AC220V power , and then turn on the power switch . Don't opposite the order , otherwise it will damage the printer .

(2) If using improper adapter may affect the printing quality or damage the printer .

(3) Do not connect a telephone line to the cash drawer interface, otherwise the printer and the phone may be damaged .

(4) When Pull or plug power cord, please hold at the hard cord part, which is marked with arrow(don't pull the power cord holding at the soft part of the cord) . Forced to pull printer power cord with cord soft part may cause printer or adapter damage .

4.3、 PAPER ROLL INSTALLATION

RP76 printers use high quality 76.0 mm 1 associated ordinary continuous paper or 2-3 associated self - copy paper with convenient automatic paper loading

Detailed Operation Instruction :


When paper sensor detects no paper, the error (ERROR) indicator , checking paper (PAPER) indicator keep light, buzzer beeps three times per1 second, waiting for paper loading . When loading paper, the paper sensor detected paper, the error (ERROR) indicator and checking paper (PAPER) indicator are all off and start the paper feeding motor and automatic paper feeding.

After feeding paper, the error (ERROR) indicator blinks. Now, press feed (FEED) button to feed paper. The error (ERROR) indicator , checking paper (PAPER) indicator are all off and the buzzer stop beeping. The printer is in ready status.

Note:

When loading paper (Do not use the paper, which is sticking to the roll core . Otherwise the printer can not detect the end of paper correctly, and may damage printer), the paper end should be neat and hold both sides of the paper insert paper straightly into the bin. The printer will automatically feed, when the paper feed motor is running. When occur paper jam and the paper end jams on paper exit, pull out the paper from back after the feed motor stop. Cut the folding paper and reload the paper

Requirements on insert roll and direction shown below:



If the roll has not been used up, but you want to remove the roll. Please follow below steps to remove roll. Do not pull out the roll from printer feeding paper area .

The operation method is as follows :

- (1) Open the printer cover
- (2) Pull up the feed paper, cutting the pulled paper
- (3) Remove the roll from the printer .
- (4) remove the remaining paper by printing feed button (not to pull out the left paper from the opposite direction of the feed paper) .

4.4、 RIBBON INSTALLATION

Be sure to use the original ribbon , not use no-name or low-quality ribbon , otherwise will shorten the life of the print head . When replacing the ribbon, make sure the printer is not receiving printing data, otherwise, the data will be lost.

Installation ribbon method is as follows :

- (1) Open the printer cover.
- (2) Follow the arrow on the ribbon to screw the ribbon cartridge to tighten the loose part of the ribbon
- (3) Insert the ribbon to the print head , and to push the ribbon cartridge until it is tight .
- (4) Follow the arrow instruction on the ribbon to screw the ribbon cartridge 5-6 cycles and to tighten the loose part of the ribbon.

5、PRINTER SWITCHES, BUTTONS AND INDICATOR

5.1 POWER SWITCH

The power switch is used to switch the printer power . It is on the left side of the printer. When press the switch " - ", turn on the printer ; When press "O", turn off the printer .

Note : Only turn on the switch after the power supply is connected .

5.2 BUTTONS AND INDICATOR

Buttons and Indicator panel are shown as below:



Buttons and indicators function:

FEED button: Feeding paper button

In standby status, press the FEED button to continuous feeding paper.

During the printing process, pressing FEED button is invalid.

After installing the roll, press FEED button to confirm the paper feeded. The printer will be into standby status.

Before power on, keep pressing the FEED button and at the same time turn on printer, it will print self-test page..

ERROR indicator(red): error indicator

Printer error indication, such as out of paper, paper jam , print head overheat, the print head error or other abnormalities.

When ERROR indicator flashing means waiting for the paper feeding

PAPER indicator (red): paper check indicator

Printing paper detection indicator, when the printer is out of paper, it keeps light.

Once the paper sensor detects paper, the indicator light become off.

POWER indicator (green) : Power indicator

Once power on, the POWER indicator keeps light.

5.3 DIP SWITCH SETTINGS

Opened the small plastic cover on the bottom of printers, will find DIP switches on the circuit board. DIP switch settings will change the printer settings .

Note:

Make sure the printer is turned off , and the power adpater has been pulled out from the power supply before setting the DIP switches .

Printer DIP switch setting function as follows:

SW	Function	ON	OFF
1	Black mark mode or not	With black	No black mark
2 3	Needle time (using multi-pages paper, the longer needle stays, the better effect of the bottom paper. This setting is mainly for multi- pages paper print)	2 3	Time (us)
		ON ON	330
		OFF ON	310
		ON OFF	290
	OFF OFF	270	
4	Select character quantity for each line (CPL) 7X9/9X9	42CPL/35CPL	40CPL/33CPL
5	Select single / bi-directional printing	single printing	bi-directional printing
6	Chinese character mode or not	Not Chinese Character	Chinese Character Mode
7 8	Transmission speed (*workable for RP76US)	7 8	Baud Rate (bps)
		ON ON	38400
		OFF ON	4800
		ON OFF	9600
	OFF OFF	19200	

6、Printer Self-test Printing

Self-test printing can detect whether the printer is working correctly. If the printer can print out self-test page, that means the printers are normal except the line connection to the PC. Otherwise the printer needs an overhaul .

Self-test can print out the firmware version No., details of the DIP switch settings, interface forms, English characters and part of Chinese characters.

Self-test operation : After connecting the printer, keep pressing the FEED button and at the same time, turn on the printer power. At this time the printer will start reset detection, and you can release the (FEED) button within 5 seconds. The printer will print out the self-test page.

At the end of the self-test page, the printer prints out the following .

Self-Test

Completed

7、Printer Serial Port


RP76 printer's serial port is RS-232 standard, and communication baud rate can be 4800bps, 9600bps, 19200bps or 38400bps optional(can be adjusted via DIP switches). It is 8 bits of data, no parity, 1 stop bit , support RTS / CTS and XON / XOFF handshake protocol.

The printer serial port pin functions are defined as follows:

Pin No.	Model Name	Signal Sources	Description
2	TXD	Printer	When using XON / XOFFhandshake protocol, the printer will send control code XON / XOFF control code to the PC .
3	RXD	host	The printer is receiving data from the PC .

7	RTS	Printer	This signal indicates the printer status. Low signal reacts the printer " busy " , and can not receive data. High signal indicates the printer " ready " to receive data
5	GND	-----	Signal Ground
4	DTR	Printer	Same as the RTS signal (Pin 7)

Printer serial port and POS host serial interface connection diagram :



Printer Serial port DB9

POS Host Serial port DB9

8、Printer Parallel Port

RP76 printer 's parallel interface is for 25PIN socket. 8-bit parallel transfer and supports the BUSY / nAck handshake protocol.


Printer parallel interface socket pin function is defined as follows :

Pin NO.	Signal Name	Signal sources	Description
1	/STB	host	Data strobe trigger pulse, when falling edge, it read-in data
2	DATA2	host	These signals respectively represent from the first to the eighth parallel data signal. For each signal, when the logic is "1" means " high" level and the logic is "0" means " low " level.
3	DATA3	host	
4	DATA4	host	
5	DATA5	host	
6	DATA6	host	
7	DATA7	host	

8 9	DATA8 DATA9	host	
10	nAck	Printer	Printer Answer Signal. It indicates that the printer has received the data of previous one byte.
11	BUSY	Printer	The "high" level indicates that the printer is " busy " , and can not receive data
12	GND	-----	Grounding, logic is "low " level
13	Select	Printer	"High " level pulled via resistance
18-25	GND	-----	Grounding, logic "low " level
15	NError(nFault)	Printer	Print error signal

9、Printer Cash Drawer Port

The printer cash drawer port is with standard RJ-11 , 6-wires socket, output DC 24V/1A and work by power signal. Plug the RJ-11 crystal plug into cash drawer port and then you can open the cash drawer via printer.



Printer cash drawer interface pin functions are defined as follows :

Pin No.	Signal	Flow Direction
1	Empty	Empty
2	Structure Ground	Output
3	Empty	Empty
4	Cash drawer driver signal	Output
5	Empty	Empty
6	Empty	Empty

10、 Black Mark Position Control Instruction

10.1 Printing mechanism and printing control relevant parameters

- (1) From the print head of printing mechanism to the printer head tear paper line position is 22 mm.
- (2) From the print head of printing mechanism to the black mark detection switch is 28 mm .

10.2 Black Mark Printing Note

- (1) Black Label must be printed on the front right side of receipt
- (2) The black mark printing size should be: 8 (W) X5 (H) mm .
- (3) The blackness of the black mark should be sufficiently saturated, reflectivity <10 % ; the other parts of the black mark printed the whiteness should be sufficient, reflectivity > 75% .

10.3 Black Mark Positioning


The institution supports the pre-printed positioning printing with black mark paper printing.

- (1) Black mark positioning control selection

Select DIP SW-1 “ON” and set GS(F command correctly and then select black mark positioning printer

- (2) Black mark detection position

Black mark is on front right side of receipt. The relationship among the black mark detection switch position, the print starting position and tear paper line position is shown as below. The printer detects the black mark position is in the forefront of the black mark to black mark detection switch center position approximately 2 mm.



A=50mm

B=28mm

C=22mm

11、 Printer Cleaning

If the print head have wastepaper, please using a soft bristle brush to clean wastepaper

12、 Troubleshooting

Printer failure, you can refer to below instruction. If still can not troubleshoot, please contact the dealer or manufacturer .

12.1 Indicator on the Control Board Not Light

Check whether the power cord is properly inserted into the printer, power adapter and power socket. Check whether the printer's power switch is turned on.

12.2 Indicator indicates normal, printer don't print

Running self-test to check if the printer is working properly . If can not be self - testing, please contact your dealer or technicians.

If the self-test can work normally, check followings:

(1) Check both ends of the connections interface between the printer and computer. Make sure that the connection specifications meets both the printer and computer requirement.

(2) The printer and the computer data transfer settings may be different. Make sure that the printers data transmission DIP switch settings is same as computer. You can print out the interface setting by printing self-test page. If the printer can not print, please contact your dealer or technicians.

12.3 Printer has Sound, but Not Printing

The ribbon cartridge may be installed improperly. Please installed the ribbon cassette correctly .

The ribbon may be worn , replace the ribbon cartridge .

12.4 Printing Vaguely

The ribbon may be worn , replace the ribbon cartridge .

12.5 Printout Lack of a Line

The print head may be damaged. Stop printing and contact your dealer or service technicians.